

HYDRAULIC WINCH

HWV10000

HWV15000

Assembly & Operating Instructions

CONTENTS

INTRODUCTION	1
SAFETY WARNINGS AND PRECAUTIONS	2
WINCH WARNINGS AND PRECAUTIONS	3
UNPACKING.....	4
INSTALLATION	4
OPERATION	8
WINCH ACCESSORIES YOU WILL NEED	9
RIGGING TECHNIQUES	9
LUBRICATION.....	10
CABLE ASSEMBLY REPLACEMENT	10
TROUBLE SHOOTING	11
WINCH ASSEMBLY DRAWING HWV10000	1 2
WINCH PARTS LIST HWV10000	1 3
SPECIFICATION(HWV10000)	1 4
WINCH ASSEMBLY DRAWING HWV15000	1 5
WINCH PARTS LIST HWV15000	1 6
SPECIFICATION(HWV15000)	1 7

INTRODUCTION

We have developed a several new series that make up the current product line. Each series in our product line has unique design characteristics; many new patented technologies are integrated into our winches. Your HWP series winch is part of our new product line and has its own salient features: two speeds, single shaft clutch and speed control, and automatic reducer gear engagement. There are three positions of reducer gear engagement, high gear, low gear, and free spool. This new technology has made winches the pinnacle in user convenience and reliability. You will take pride in knowing that your new winch has been designed to work as hard as you and that it will be there when you need it.

Congratulations on your purchase of a highest class advanced powerful two speed winch. We design and build winches to strict specifications and with proper use and maintenance should bring you years of satisfying service.

 **WARNING** - Read, study and follow all instructions before operating this device. Failure to heed these instructions may result in personal injury and/or property damage.

Your winch can develop tremendous pulling forces and if used unsafely or improperly could result in property damage, serious injury or death. Throughout this manual you will find the following symbols for caution, warning and danger. Pay particular attention to the notes preceded by these symbols as they are written for your safety. Ultimately, safe operation of this device rests with you, the operator.



This indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. This notation is also used to alert you against unsafe practices.



This indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

SAFETY WARNINGS AND PRECAUTIONS

 **WARNING:** When using the tool, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the equipment. Read all this instructions before using this tool!

 **WARNING –Do not use winch to lift (vertically).**

 **WARNING – Keep children away.** Children must never be allowed in the work area Do not let them handle machines, tools, or extension cords.

 **WARNING – Store idle equipment.** When not in use, tools must be stored in a dry location to inhibit rust. Always lock up tools and keep out of reach of children.

 **WARNING – Dress properly.** Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes and non-skid footwear are recommended when working. Wear restrictive hair covering to contain long hair.

 **WARNING – Use eye and ear protection.** Always wear impact safety goggles. Wear a full face shield if you are producing metal filings or wood chips. Wear a dust mask or respirator when working around metal, wood, and chemical dusts and mists.

 **WARNING – Maintain tools with care.** Keep tools sharp and clean for better and safer performance. Follow instructions for lubricating and changing accessories. Inspect tool cords periodically and, if damaged, have them repaired by an authorized technician. The handles must be kept clean, dry, and free from oil and grease at all times.

 **WARNING – Disconnect switch.** Unplug switch when not in use.

 **WARNING – Stay alert.** Watch what you are doing, use common sense. Do not operate any tool when you are tired.

 **WARNING – Check for damaged parts.** Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for alignment and binding of moving parts; any broken parts or mounting fixtures; and any other condition that may affect proper operation. Any part that is damaged should be properly repaired or replaced by

a qualified technician. Do not use the tool if any switch does not turn “On” and “Off” properly.

 **WARNING – Replacement parts and accessories.** When servicing, use only identical replacement parts. Use of any other parts will void the warranty. Only use accessories intended for use this tool.

 **WARNING – Do not operate tool if under the influence of alcohol or drugs.** Read warning labels on prescription to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate the tool.

WINCH WARNINGS AND PRECAUTIONS

 **WARNING** – Keep hands and body away from Fairlead (cable intake slot) when operating.

 **WARNING** – Secure vehicle in position before using winch.

 **WARNING** – Be certain winch is properly bolted to a structure (or vehicle) that can hold the winch load.

 **WARNING** – Do not use inappropriate attachments to extend the length of the winch cable.

 **WARNING** – Never lift people or hoist loads over people.

 **WARNING** – Never come in between the winch and the load when operating.

 **WARNING** – Do not apply load to winch when cable is fully extended. Keep at least 5 full turns of cable on the spool.

 **WARNING** – After moving an item with the winch, secure the item. Do not rely on the winch to hold it for an extended period.

 **WARNING** – Examine winch before using. Components may be affected by exposure to chemicals, salts, and rust.

 **WARNING** – Never operate winch if cable shows any signs of weakening, such as knotting or kinking.

 **WARNING** – Do not cross over or under cable when the winch is under load.

 **WARNING** – Do not move your vehicle with the cable extended and attached to the load. You could easily exceed the winch rating and snap the cable.

 **WARNING** – Use gloves while handling cable.

 **WARNING** – When the vehicle is parked on an incline you should use wheel chocks.

 **WARNING** – Re-spool cable properly avoiding cable misalignment.

 **WARNING** – The winch cable must be wound onto the drum under a load of at least 10% of the rated line pull or the outer wraps will draw into inner wraps and damage winch cable

 **WARNING** – Before operating the winch under load you should check proper function of the winch by engaging and disengaging the clutch, by operating the directional controls, and operating the speed controls. This will ensure that the winch is working properly and will help prevent unintended damage and injury. Cycling the winch prior to loading will also ensure the gears are properly aligned.

UNPACKING



When unpacking, check to make sure all parts are included. Refer to Assembly Drawings and Parts List (both with the like item numbers) at the end of this manual.

INSTALLATION


1. Your winch is designed with a bolt pattern that is standard in this class of winch. Many winch mounting kits are available that utilize this bolt pattern for the most popular vehicle and mounting channels. If you cannot find a kit locally, contact us and we will provide you with the name of a dealer near you. If you will utilize the mounting channel you must ensure that it is mounted on a flat surface so that the three major sections (motor, drum and gear housing) are properly aligned. Proper alignment of the winch will allow even distribution of the full rated load.
2. Mount winch to the vehicle using high strength cap screw. It should be aligned and secured to a solid part of the vehicle (front or rear) where the the full rated load will be evenly distributed.

3. Please refer to installation illustration.


Working hydraulic principle chart and installation illustration:




Below is installation illustration of HWV10000:



Below is installation illustration with roller fairlead of HWV10000:



Below is installation illustration of HWV15000:



Caution:

The hydraulic system needs a relief valve to ensure the system safety. The absence of such a valve could cause serious injury and damage the winch.

Winch battery cables should be placed so that there is a small amount of slack in the cable.

If you are using a heat exchanger with your application to cool the hydraulic fluid you should refer to the illustration about mounting.

You should check the hydraulic fluid level and replace any that may have seeped out. The hydraulic system should be purged at this time. Listed below are the directions on how to purge the hydraulic system.

- 1) Start the engine.
- 2) Power the winch to draw out about 5 feet of cable.
- 3) Shut down the engine.
- 4) Check the fluid level and fill as needed.
- 5) Repeat steps 1 through 4 as necessary.
- 6) Start the engine.
- 7) Move the cable into the desired position.
- 8) Turn the wheels on the vehicle from the right lock to the left lock positions five times to help bleed the hydraulic system.
- 9) If the hand control unit is working backwards, simply exchange the brown and the white wire connections within the valve.

Test the winch for proper operation. Refer to the section below.

OPERATION

WARNING

- 1 Make sure clutch is totally engaged before starting any winch operation;**
- 2 Stay clear and away from raised loads;**
- 3 Stay clear of cable while pulling do not try to guide cable;**
- 4 A min. of 5 wraps of cable around the drum barrel.**

General information:

The Winch's standard equipments contain gear reducer、drum、hydraulic motor、solenoid valve、switch assembly、female connector and plumbing fittings. The winch obtains its pressure from the vehicle's existing power steering pump or other hydraulic power. The winch is totally sealed, can be used underwater.

There are several other ways to supply power to the winch. The first way is to use an individual pump for engineering use. The second way is to provide the winch's hydraulic pressure is with the vehicle's exiting power steering pump (See Installation Instructions).

① Use a suitable individual pump, which doesn't have an oil pressure relief valve. It will supply pressure for both the steering box and the winch.

② Use a combined pump with an integrated oil valve. The oil valve will supply two kinds of flow based on the difference in demand. One type of flow will be constant and should be used with the steering system. The other will provide higher pressure and is for engineering use.

Caution:

Hydraulic system needs an relief valve to make sure the system is safe; If there is not relief valve in the system; it would be serious danger and the system can't operation. If your winch driven by an existing hydraulic power system, the relief valve is also existing.

Winch working demonstration:

1. Disengage the clutch by turning the clutch to the "CLUTCH OUT" position.
2. Grab the cable assembly and pull the cable to the desired length, then attach to item being pulled.

Caution: Always leave at least five turns of cable on the drum; Review Winch Safety Warnings and Precautions on page 2, 3 before continuing.

3. Reengage the clutch by turning the clutch assembly to the “CLUTCH IN” position as needed.
4. Test-run winch in both directions. Turn the winch in each direction for about one or two seconds meantime make the clutch totally engaged automatically.
5. While standing aside of the tow path, hold and operate the switch assembly supplied by your choice. Wait until the motor stops before reversing directions.

WINCH ACCESSORIES YOU WILL NEED

NOT INCLUDED WITH YOUR WINCH


Gloves – For handling the wire rope and hook strap.

Anchor Strap/Chain – Tree saver anchor straps are made of high quality nylon with high tensile strengths up to 15000lbs.

Heavy Blanket – place on the cable to absorb energy should the wire rope break.


RIGGING TECHNIQUES

Self-Recovery




Locate a suitable anchor such as a strong tree trunk or boulder.

Always use a sling as an anchor point. **⚠ CAUTION** Do not attach the clevis hook back onto the cable as this could cause damage to the cable. As shown in Fig 3.1




⚠ CAUTION Do not winch from an acute angle as the wire rope will pile up on one side of the drum causing damage to wire rope and the winch. Fig 3.2

Short pulls from an angle can be used to straighten the vehicle. Long pulls should be done with the wire rope at a 90° angle to the winch/vehicle.




When pulling a heavy load, place a blanket or jacket over the wire rope five or six feet from the hook. In the event of a broken cable it will dampen the snap back. For additional protection open the hood of the vehicle as shown in Fig 3.3



For pulls over 70% rated line pull, we recommend the use of the snatch block/pulley block to double line the wire rope. Fig 3.4

This reduces the load on the winch and the strain on the rope by up to 50% depending on the included angle.



WARNING - Never use your winch for overhead hoisting or for lifting people or moving people.

LUBRICATION

1. All moving parts within the Winch having been Lubricated using high temperature lithium grease at the factory. No internal lubrication is required.
2. Lubricate Cable Assembly periodically using a light penetrating oil.

CABLE ASSEMBLY REPLACEMENT

If the wire rope has become worn or is beginning to show signs of strands breaking, it must be replaced before being used again.

1. Turning clutch to the "CLUTCH OUT" position.
2. Extend cable assembly to its full length. Note how the existing cable is connected to the drum.
3. Remove old cable assembly and attach new one as the old cable connected to the drum. Insert the end of the new rope and secure the screw being tightly screwed
4. Turning clutch to the "CLUTCH IN" position.
5. Retract cable assembly onto drum, first five wraps being careful not to allow kinking, then winch cable must be wound onto the drum under a load of at least 10% rated line pull.




WARNING - Only replace the wire rope with the identical replacement part recommended by the manufacturer.

TROUBLE SHOOTING

SYMPTOM	POSSIBLE CAUSE	SUGGESTED ACTION
Winch does not turn .	-Insufficiently hydraulic system pressure. -Improper connections of hydraulic system, no oil into motor.	-Check relief valve regulate pressure. -Check all the plumbing fixtures according to the working principle chart. -Defective directional control valve.
Motor runs but Cable drum does not turn	- The clutch is Not engaged	-Turn the clutch to the high or lows peed position. If problem still persists, a qualified technician needed to check and repair.
Winch drum runs slowly or without normal power.	-Insufficient pressure or oil flow -Insufficient fluid in the system - Wrong winch working direction.	-Bump is not suitable or defective. Change a new one or a suitable one -Check fluid level. Add fluid until full. -Change the connection of balance valve and motor.
Winch cannot spool off wire rope with load smoothly.	-Wrong winch working direction.	-Change the connection of balance valve and motor.

WINCH ASSEMBLY DRAWING HWV10000



WINCH PARTS LIST HWV10000

No.	Part #	Qty	Description	Remark
1	HV1000001	1	High-pressure oil tube	
2	HV1000002	2	Oil connection	
3	HV1000003	2	Combination Washer 14	
4	HV1000004	2	Cap Screw M12 x 30	
5	HV1000005	2	Lock Washer Φ12	
6	HV1000100	1	Hydraulic Motor	
7	HV1000006	1	Blanced valve	
8	HV1000007	4	Cap Screw M8 x 55	
9	HV1000008	12	Lock Washer Φ8	
10	HV1000009	8	Screw M8 x 30	
11	HV1000010	1	Brake stents	
12	HV1000011	3	Brake block	
13	HV1000012	2	Friction plate	
14	HV1000013	2	O-ring seal 100*3.55	
15	HV1000014	1	Piston	
16	HV1000015	1	O-ring seal 140*2.65	
17	HV1000016	2	Disk spring	
18	HV1000017	2	O-ring seal 118*3.55	
19	HV1000018	1	Motor bracket	
20	HV1000019	1	Coupling	
21	HV1000020	1	Transmission shaft	
22	HV1000021	2	Bearing bush	
23	HV1000022	2	Ring Seals	
24	HV1000023	8	Screw M10 x 25	
25	HV1000024	16	Lock Washer Φ10	
26	HV1000025	1	Stand bar (b)	
27	HV1000026	1	Stand bar (a)	
28	HV1000027	2	Screw M8 x 15	
29	HV1000200	1	Drum Assembly	
30	HV1000028	1	Coupling I	
31	HV1000029	16	Cap Screw M6 x 20	
32	HV1000030	16	Lock Washer Φ6	
33	HV1000031	1	End Bearing	
34	HV1000300	1	Gear Carrier Assembly (Output)	
35	HV1000032	2	Gasket	
36	HV1000033	1	Gear-Ring (Output)	
37	HV1000400	1	Gear Carrier Assembly (Input)	
38	HV1000034	1	Circlip for hole Φ125	
39	HV1000035	1	Gear-Ring (Input)	
40	HV1000036	1	Gear—Input Sun	
41	HV1000037	1	Trust Washer	
42	HV1000038	1	Axle sleeve	
43	HV1000039	1	Cover-Gear Housing	
44	HV1000500	1	Clutch Assembly	
45	HV1000040	8	Screw M10 x 35	
46	HV1000041	8	Think Flat Washer Φ10	
47	HV1000600	1	Roller Fairlead	
48	HV1000700	1	Cable Assembly	
49	HV1000800	1	Tensioned Of Steel Wire Supplied Assembly	

SPECIFICATION(HWV10000)

Rated line pull	10000 lbs (4536 kgs)
Motor displacement	100ml/r
Oil flow	5~60L/min
Pressure	15Mpa
Gear reduction ratio	17.6:1
Cable (Dia. × L)	Ø13/32"×83.7' (Ø10.2mm×25.5m)
Drum size(Dia. × L)	Ø4.0 "×10.0" (Ø102mm×253mm)
Mounting bolt pattern	14.7 "×4.5 " (374.2mm×114.3mm) ; 11.5 "×6.7" (291.6mm×171.2mm) 8-M10
Overall dimensions (L×W×H)	25.5"×9.3"×9.7" 647mm ×237mm ×248mm
Net weight lbs(kg)	112.4 51


Pull , Speed, Pressure, Flow (First layer)

Line pull lbs (kgs)	Pressure Mpa(Psi)	Flow G/min (L/min)	Line speed ft/min(m/min)
0	3.0(435.1)	1.3(5)	3.0(0.9)
4000(1814)	6.8(986.2)	2.6(10)	5.9(1.8)
6000(2722)	9.2(1334.3)	5.2(20)	11.8 (3.6)
8000(3629)	12.0(1740.4)	10.4(40)	23.6(7.2)
10000(4536)	15.0(2175)	15.6(60)	36.1(11)

Line Pull And Rope Capacity Inlayer

Layer of wire rope	Rated line pull lbs(kgs)	Total rope on drum ft (m)
1	10000(4536)	23.0(7.0)
2	7355(3336)	49.2(15.0)
3	6780(3075)	78.7(24.0)
4	5711(2591)	83.6(25.5)

WINCH ASSEMBLY DRAWING HWV15000



WINCH PARTS LIST HWV15000

No.	Part #	Qty	Description	Remark
1	HV1500001	1	High-pressure oil tube	
2	HV1500002	2	Oil connection Oil	
3	HV1500003	2	Combination Washer 14	
4	HV1500004	2	Cap Screw M12 x 30	
5	HV1500005	2	Lock Washer Φ12	
6	HV1500100	1	Hydraulic Motor	
7	HV1500006	1	Blanced valve	
8	HV1500007	4	Cap Screw M8 x 55	
9	HV1500008	36	Lock Washer Φ8	
10	HV1500009	8	Screw M8 x 30	
11	HV1500010	1	Brake stents	
12	HV1500011	3	Brake block	
13	HV1500012	2	Friction plate	
14	HV1500013	2	O-ring seal 100*3.55	
15	HV1500014	1	Piston	
16	HV1500015	1	O-ring seal 140*2.65	
17	HV1500016	2	Disk spring	
18	HV1500017	2	O-ring seal 118*3.55	
19	HV1500018	1	Motor mounting plate	
20	HV1500019	3	Gasket	
21	HV1500020	1	Motor bracket	
22	HV1500021	24	Screw M8 x 25	
23	HV1500022	1	Coupling	
24	HV1500023	1	Transmission shaft	
25	HV1500024	2	Bearing bush	
26	HV1500025	2	Ring Seals	
27	HV1500026	8	Screw M10 x 25	
28	HV1500027	16	Lock Washer Φ10	
29	HV1500028	2	Stand bar	
30	HV1500029	2	Screw M8 x 15	
31	HV1500200	1	Drum Assembly	
32	HV1500030	1	Coupling I	
33	HV1500031	1	End Bearing	
34	HV1500300	1	Gear Carrier Assembly (Output)	
35	HV1500032	1	Gear-Ring (Output)	
36	HV1500400	1	Gear Carrier Assembly (Input)	
37	HV1500033	1	Circlip for hole Φ125	
38	HV1500034	1	Gear-Ring (Input)	
39	HV1500035	1	Gear—Input Sun	
40	HV1500036	1	Trust Washer	
41	HV1500037	1	Axle sleeve	
42	HV1500038	1	Cover-Gear Housing	
43	HV1500500	1	Clutch Assembly	
44	HV1500039	8	Screw M10 x 35	
45	HV1500040	8	Think Flat Washer Φ10	
46	HV1500600	1	Roller Fairlead	
47	HV1500700	1	Cable Assembly	
48	HV1500800	1	Tensioned Of Steel Wire Supplied Assembly	

SPECIFICATION(HWV15000)

Rated line pull	15000 lbs (6804 kgs)
Motor displacement	160ml/r
Oil flow	5~60L/min
Pressure	17.5Mpa
Gear reduction ratio	17.3:1
Cable (Dia. × L)	Ø15/32"×86.9' (Ø12mm×26.5m)
Drum size(Dia. × L)	Ø5.0 "×10.5" (Ø127mm×266mm)
Mounting bolt pattern	12.0 "×4.5 " (303.5mm×114.3mm) ; 14.5 "×6.7" (368.5mm×171.2mm) 8-M12
Overall dimensions (L×W×H)	28.9"×11.8"×10.9" 735mm ×300mm ×277mm
Net weight lbs(kg)	184.3 83.6

Pull , Speed, Pressure, Flow (First layer)

Line pull lbs (kgs)	Pressure Mpa(Psi)	Flow G/min (L/min)	Line speed ft/min(m/min)
0	2.0(290)	2.6(10)	4.2(1.3)
8000(3629)	9.2(1337)	5.2(20)	8.5(2.6)
10000(4536)	11.5(1627)	7.9(30)	12.4 (3.8)
12000(5448)	14.0(2030)	10.4(40)	16.7(5.1)
15000(6810)	17.5(2537)	15.6(60)	23(7)

Line Pull And Rope Capacity Inlayer

Layer of wire rope	Rated line pull lbs(kgs)	Total rope on drum ft (m)
1	15000(6804)	29.5(9.0)
2	12791(5807)	65.6(20.0)
3	11150(5062)	86.9(26.5)